



SPARE PARTS LIST FOR SPIRAL MIXER ABSFBM-50

PART NO.	DESCRIPTION
01	Castors
02	Adjustable foot plates
03	Drive shaft
04	Chain wheel
05	Chain 5/8" x 1374mm
06	Frame
07	Bearing housing
08	Bearing No. UCF206 x 2 pcs
09	Guide roller for bowl x 2 pcs
10	Back cover
11	Motor 1.5/3Kw, 8/4P
12	Mounting plate for motor
13	Pin of mounting plate
14	Protection cover on top of bowl
15	Motor pulley
16	Driven pulley
17	V-Belt 7M850 x 3pcs
18	Pulley
19	Top cover
20	V-Belt 7M1060 x 4pcs
21	V-Belt A-41 x 1pc
22	Touch digital panel
23	Electric contractors
24	Fixing nut for main shaft
25	Main shaft pulley
26	Top bearing for spiral shaft No. 6206 x 1 pc
27	Bearing housing
28	Main shaft
29	Bearing housing for main shaft
30	Bottom bearing for spiral shaft No. 6305 x 2 pcs
31	Safety cover
32	Clamping block for spiral
33	Center pillar
34	Kneading spiral
35	Bowl
36	Top bearing No. 6010V x 2 pcs
37	Bearing housing
38	Bearing No. 6207V x 1 pcs
39	Chain wheel
40	Fixing nut
41	Bowl plate with shaft
42	Swivel castors